Art.-Nr. 3914902

Bedienungsanleitung

Sport-Thieme Schaukelsitz „Jungle"

Vielen Dank, dass Sie sich für dieses Produkt entschieden haben!
Damit Sie viel Freude an diesem Produkt haben und die Sicherheit gewährleistet ist, sollten Sie diese Anleitung vor dem Gebrauch zunächst vollständig durchlesen. Bewahren Sie die Anleitung gut auf. Für Fragen und Wünsche stehen wir Ihnen gerne zur Verfügung.



Lieferung ohne Seil

0226518 · © 2025 Sport-Thieme GmbH

SPORT-THIEME
Sport-Thieme GmbH · 38367 Grasleben · sport-thieme.de
Tel. 05357 18181 · Fax 05357 18190 · info@sport-thieme.de

Produktbeschreibung

Verwendungszweck

Dieses Produkt ist nur für den bestimmungsgemäßen Gebrauch zu verwenden. Missbrauch jeglicher Art führt zur Beeinträchtigung der Sicherheit und zum Verlust der Gewährleistung!
Mit dem Sport-Thieme Schaukelsitz „Jungle“ verwandeln Sie Taue in ein vielseitiges Schaukelgerät zum Schwingen, Schaukeln und Drehen.

Maße: 22 x 8 cm
Gewicht: 0,6 kg
Maximale Belastbarkeit: 50 kg

⚠ Achtung!

- Lange(s) Seil/Schnur/Kette. Strangulationsgefahr!
- Achten Sie auf ausreichenden Fallschutz!
- Es muss ein ausreichender Sicherheitsabstand gewährleistet sein!
  In diesem Bereich dürfen sich während der Nutzung keine Gegenstände oder Personen befinden!
- Scharfe Kanten können die Oberfläche beschädigen!
- Benutzung nur durch eine Person!
- Benutzung nur unter unmittelbarer Aufsicht von Erwachsenen!
- Nicht für Kinder unter 3 Jahren geeignet!

Modifikation von Produkten:
Modifikation jeglicher Art führt zur Beeinträchtigung der Sicherheit und zum Verlust der Gewährleistung!

Montage

Benötigte Werkzeuge: /
Benötigte Personenzahl: 1
Benötigte Zeit: 1 Min.



Montageschritt 1
- Schieben Sie das Seil durch die große Öffnung in der Mitte des Schaukelsitzes.



Montageschritt 2
- Ziehen Sie das Seil gemäß der Abbildung durch die Öffnung zwischen den beiden Zylindern.



Montageschritt 3
- Zurren Sie das Seil straff.

User Manual

Prod. Code 3914902

Sport-Thieme ‘Jungle’ Swing Seat

Thank you for choosing this product!
Please read the following notes carefully before use so you can enjoy this product safely and keep these instructions for future reference. If you have any questions, our team is here for you.



Delivery without rope

0226518 · © 2025 Sport-Thieme GmbH

SPORT-THIEME
Sport-Thieme GmbH · 38367 Grasleben, Deutschland · sport-thieme.com
Tel. +49 53 57 181 503 · Fax +49 53 57 181 921 · info@sport-thieme.com

Product description

Intended use:

This product must only be used for its intended purpose. Misuse of any kind will compromise safety and render the warranty void! With the Sport-Thieme “Jungle” swing seat, you can transform ropes into a versatile swinging device for swinging, rocking and turning.

Dimensions: 22 x 8 cm
Weight: 0,6 kg
Maximum load: 50 kg

Caution!

- Long rope/cord/chain. Danger of strangulation!
- Please ensure adequate fall protection!
- Whilst the equipment is in use, people and objects should remain at a safe distance!
- Sharp edges can damage the surface!
- Use by one person only!
- To be used only under direct adult supervision!
- Not suitable for children under 3!

Modification of products:
Modifications of any kind will compromise safety and render the warranty void!

Assembly

Tools required: /
Number of people required: 1
Time required: 1 Min.



Assembly step 1
- Push the rope through the large opening in the middle of the swing seat.



Assembly step 2
- Pull the rope through the opening between the two cylinders as shown in the illustration.



Assembly step 3
- Lash the rope tightly.

Maintenance and care / additional information

Instructions for regular checks:

- Perform a visual inspection at regular intervals.
- Due to our continuous quality control of the products, technical changes may occur which may lead to minor changes to the instructions.
- Check the bolt connections regularly for tightness.
- Check the condition of the ropes, as use may cause wear (e.g. roughening, fraying, cuts).